

Hawkmate™

A Tool Spackling System

PO Box 596 Hicksville, NY 11714

Email: info@hawkmate.com

Assembly Instructions

Step 1.

Turn Hawk so handle is facing upward



Step 2.

Unscrew handle from Hawk



Step 3.

Place Hawkmate on Hawk



Step 4.

Screw handle back into place on Hawk

Make sure tension is correct to keep Spackling knives in place

